

MULTI-RECEIVER

With 8 bits dip switch, the user can make difference combination for difference remote brand. The brands selection show as table 1. In MULTI-RECEIVER, there're 2 independent channels. Each channel has independent learn button S1, S2 and L1,L2. The MULTI RECEIVER can be worked at the input AC/DC 12V~30V. However, it's better to change the PIS according to the power input. If the input is great than 24V, shorten pin 2&3; shorten 1&2 if input less than 24V. The memory card can be removed from board for read, copy and backup. (CONTACT CAPACITY 24V/0.5A)

How to entry remote and Erase all remote

Entry one button or remote:

1. First, selecting the correct brands for remote will be entry by dip switch;
2. Press the learn button, the LED turn on. Press the button on the remote, the LED flashes 4 times, this button entry into the successfully.
3. Repeat step 2 for another button.
4. 2 channels works at same.


Erase all data in memory card:

Pressing and holding either learn button, the LED start flash. Keep holds pressing this button until the LED turn off.

All data in the memory card will be erased permanently.

Notice: Be carefully for erasing all data in the memory card.

The data will be erased permanently and cannot be recovered.



	Stav DIP prepínačov	Značka	Frekvencia	
1		NICE FLORS	433.92MHz	
2		MARANTEC	433.92MHz	
3		UNIVERSAL FIXE CODE	433.92MHz	Fixe code
4		FAAC SLH Rolling Code	433.92MHz	
5		Liftmaster	433.92MHz	
6		Universal Rolling code	433.92MHz	433.92 MHz
7		Fix Code	300.00MHz	frec. 300.00MHz
8		Fix Code	310.00MHz	frec. 310.00MHz
9		Fix Code	315.00MHz	frec. 315.00MHz
10		Fix Code	318.00MHz	frec. 318.00MHz
11		Fix Code	330.00MHz	330.00MHz
12		Fix Code	390.00MHz	390.00MHz

13		Rolling code fixe code	315.00MHz	
14		GO JCM	868 MHz	
15		Liftmaster Rolling Code Billioncode	390.00MHz	
16		Liftmaster Rolling Code	315.00MHz	
17		Hormann Marantec Berner	868.00MHz	
18		FAAC SLH	868.00MHz	
19		Prastel	433.00MHz	
20		Sommer	868.00MHz	
21		Sommer	433,34MHz	
22		Liftmaster Rolling Code	868.00MHz	
23		Clema Mastercode	433MHz	

MULTI-RECEIVER

Pomocou 8 DIP prepínačov môže užívateľ nastaviť prijímač pre považovanú značku vysieláča. Kombinácie prepínačov pre jednotlivé značky vysieláčov sú v tabuľke. Multi-receiver obsahuje dva nezávislé kanály, ktoré pracujú pre rovnakú značku. Každý kanál má jedno tlačidlo pre naladenie vysieláča, tlačidlo S1 a LED L1 pre 1. kanál, tlačidlo S2 a LED L2 pre 2. kanál. Prijímač môže byť napájaný napätím AC/DC 12V~30V. Avšak je lepšie nastaviť JUMPER podľa vstupného napätia. Ak má napájacie napätie vyššiu hodnotu ako 24V, tak je potrebné prepojiť PIN 2&3, ak má napájacie napätie nižšiu hodnotu ako 24V, tak je potrebné prepojiť PIN 1&2. Prijímač obsahuje pamäťovú kartu, ktorú je možné vybrať pre čítanie, kopírovanie a zálohovanie kódov. (Max. zaťaženie relé je 0,5 A)


Uloženie vysieláča do pamäti:

1. Nastavte DIP prepínače na značku vysieláča, ktorý chcete naladiť.
2. Stlačte tlačidlo prvého kanálu na 2 sekundy, príslušná LED zostane svietiť. Stlačte tlačidlo na vysieláči. Príslušná LED blikne 4 krát, ak uloženie vysieláča prebehlo úspešne.
3. Druhý kanál funguje rovnako.

Vymazanie vysieláča s pamäti:

Stlačte a držte stačené tlačidlo, LED dióda začne blikat'. Držte tlačidlo, kým LED dióda prestane blikat'. Týmto postupom vymažete všetky uložené vysieláče.

Upozornenie: Buďte opatrný pri mazaní pamäti prijímača, pretože dáta budú vymazané trvale a nie je ich možné obnoviť.



	Stav DIP prepínačov	Značka	Frekvencia	
1		NICE FLORS	433.92MHz	
2		MARANTEC	433.92MHz	
3		UNIVERSAL FIXE CODE	433.92MHz	Fixe code
4		FAAC SLH Rolling Code	433.92MHz	
5		Liftmaster	433.92MHz	
6		Universal Rolling code	433.92MHz	433.92 MHz
7		Fix Code	300.00MHz	frec. 300.00MHz
8		Fix Code	310.00MHz	frec. 310.00MHz
9		Fix Code	315.00MHz	frec. 315.00MHz
10		Fix Code	318.00MHz	frec. 318.00MHz
11		Fix Code	330.00MHz	330.00MHz
12		Fix Code	390.00MHz	390.00MHz

13		Rolling code fixe code	315.00MHz	
14		GO JCM	868 MHz	
15		Liftmaster Rolling Code Billioncode	390.00MHz	
16		Liftmaster Rolling Code	315.00MHz	
17		Hormann Marantec Berner	868.00MHz	
18		FAAC SLH	868.00MHz	
19		Prastel	433.00MHz	
20		Sommer	868.00MHz	
21		Sommer	433,34MHz	
22		Liftmaster Rolling Code	868.00MHz	
23		Clemsa Mastercode	433MHz	